



# VTech InnoTab Max Cover Replacement

Cover replacement guide for the VTech InnoTab Max.

Written By: Alexander Bees



## INTRODUCTION

This guide will show any user how to replace the cover on a VTech InnoTab Max.

---



### TOOLS:

- [J1 Screwdriver Bit](#) (1)
  - [64 Bit Driver Handle](#) (1)
  - [iFixit Opening Tools](#) (1)
  - [Magnetic Project Mat](#) (1)
-

## Step 1 — Cover



- Remove all screw caps from the back panel using a metal spudger.

## Step 2



- Next remove all of the now uncovered screws.
- i** If there is a cartridge in the device make sure to remove it.



## Step 3



- Now that all of the screws have been removed, pry the back cover off using a plastic opening tool.

## Step 4



- Here you can see the back cover has been fully removed and you can now access the front cover.
- To remove the front cover, remove the springs holding the pictured brackets in place, then pull it away.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-09 08:40:03 PM.